






## MISSILE BLASTER with the MEGA MISSILE™







Place your feet on the Base, and use the Handles to Pump the missile blaster approximately 16 times.

NOTE: To launch the MEGA MISSILE, hold the missile blaster level, or at up to a 45° angle to the ground, or it will not launch.








## DART BLASTER with 6 micro darts




Slide the Multi Shot Mechanism forward and back to its original position.








NOTE: You must slide the Multi Shot Mechanism forward and back to its original position before pumping the dart blaster. Otherwise, only one dart will launch and blast mode will not function properly.







## P/N: 6776310000



The Incredible Hulk, the Movie: © 2008 MVL Film Finance LLC. Marvel, The Incredible Hulk, all character names and their distinctive likenesses: TM & © 2008 Marvel Entertainment, Inc. and its subsidiaries. All Rights Reserved.

®\* and/or TM\* & © 2008 Hasbro. All Rights Reserved.
TM & ® denote U.S. Trademarks.

U.S. pat. Nos. 5,529,050 & 7,267,118.



Not suitable for children under 3 years because of small parts — choking hazard.

Questions? Call 1-800-327-8264

